

Amplifier and Multiplier Module

Handling and Operation

1. Please observe proper ESD practices.
2. Attach clip leads or solder wire to the bias pin and ground.
**Note: Do not use wire larger than 26 Gauge.*
3. Turn on the power supply before connecting to the amplifier.
4. Ensure the voltage is set at 7.5 to 12V.
**Note: For GaN Amps, set the voltage to 14V.*
5. Turn off the power supply.
6. Now that the voltage is set, connect the power supply.
7. Turn on the power supply.
**Note: DO NOT slowly ramp up the voltage.*